

# C275 TEMPLATE

LINE UP WITH VERTICAL LINE ON DOOR

110mm [ $4\frac{5}{16}$ "]

5.6mm [ $\frac{1}{4}$ "]

Cylinder Hole -  
Single cylinder :  
Drill half the door  
thickness from outside.  
Double cylinder :  
Drill through from both sides.

ASA STRIKE LIP POSITION

$\phi 31.8$ mm [ $\phi 1\frac{1}{4}$ "]

LOCK CENTER

STRIKE CENTER

15.4mm [ $\frac{5}{8}$ "]

14.6mm [ $\frac{9}{16}$ "]

$\phi 16$ mm [ $\phi \frac{5}{8}$ "]

ASA STRIKE LIP POSITION

Thumb Turn Hole  
Drill half the door  
thickness from inside.

70mm [ $2\frac{3}{4}$ "] BASCKSET

52-DCA-70  
BAP011

CENTER LINE

32mm [ $1\frac{1}{4}$ "]

FACE PLATE 32mm

25.4mm [1"]

FACE PLATE 25.4mm

24mm [ $\frac{15}{16}$ "]

LOCK  
MORTISE

39.4mm [ $1\frac{9}{16}$ "]

78.8mm [ $3\frac{1}{8}$ "]

146mm [ $5\frac{3}{4}$ "]

2.25mm [ $\frac{1}{16}$ "]

TEAR OFF AND POSITION ON DOOR

CENTER LINE